



HKUSTx: ELEC1200.3x A System View of Communications: From Signals to Packets (Part 3)



Bookmarks

- ▶ Pre-course Materials
- ▶ Topic 1: Course Overview
- ▶ Topic 2: The Link Layer
- ▶ Topic 3: The Network Layer
- ▶ Topic 4: Routing
- ▶ Topic 5: The Transport Layer
- ▶ Topic 6: Reliable Transfer Protocols

Topic 7: The Application Layer > 7.4 Lab 4 - Application Layer > Lab 4 - Download and Setup Wireshark



Bookmark

Download Wireshark

We will use the Wireshark network protocol analyzer (a packet sniffer) to analyze some specific application protocols. Please **download** Wireshark here:

<https://www.wireshark.org/download.html> and install it.

If you use Linux, Wireshark packages are available for most platforms and you can use them without installing Wireshark from source code. For example, in Ubuntu you can install Wireshark 1.6.7 using the command:

```
sudo apt-get install wireshark
```

Setup Wireshark (Windows)

In this section, we describe the setup of Wireshark for these labs assuming that you are using Windows. Setup for other operating systems is similar. We provide some notes on the setup under Linux in the next section.

When you start Wireshark, you should see the window shown below as Figure 1. The area highlighted by the lower red box shows the link layer connections available on your computer. This may differ according to your computer setup. For example, your

▼ Topic 7: The Application Layer

7.1 Application Layer

Week 4 Quiz due Feb 15, 2016 at 15:30 UTC

7.2 Hypertext Transfer Protocol (HTTP)

Week 4 Quiz due Feb 15, 2016 at 15:30 UTC

7.3 Domain Name System (DNS)

Week 4 Quiz due Feb 15, 2016 at 15:30 UTC


7.4 Lab 4 - Application Layer

Lab due Feb 15, 2016 at 15:30 UTC

► Topic 8: Course Review

► MATLAB download and tutorials

computer may show a "Wi-Fi" interface. Select the connection you are using to access the internet by clicking on it. In the example shown here, we have selected the "Local Area Connection" shown in Figure 1.






Figure 1: Wireshark Window.

From the menu, select Capture => *Options*. A window similar to that shown in Figure 2 below will appear. Click on the button next to the link layer interface you are using to expand the information about that link. As illustrated in Figure 2, you will be able to see the IP address of the link you are using on your computer.




Figure 2: Wireshark Capture Options Window

Tick the following options under "Options" pane of the window as shown in Figure 3. After that close the window, by clicking on "Close" in the lower right corner.




Figure 3: Wireshark Capture Options Window.

Next, setup the time display format by selecting "View=>Time Display Format" as shown in Figure 4.





Figure 4: Wireshark View Window

Setup Wireshark (Linux)

If you are using the Linux operation system, select *Applications => Internet => Wireshark Network Analyzer*.

Then you need to enter password for "root".



If you need to ask someone else to grant permission for you, you could click on *"Run Unprivileged"* in the pop-up dialog box, and then enter the following line in the terminal after login as "root":

```
setcap 'CAP_NET_RAW+eip CAP_NET_ADMIN+eip' /usr/sbin/dumpcap
```

When you select "Capture Options", the Capture Options window will be displayed as shown in Figure 5. Choose the link layer interface you are using from the drop down box at the top. The IP address of this link will be shown below. Click on the options so that they match those shown in Figure 5. In this example, the computer is connected to the Internet via a wired Ethernet interface. The computer is using "eth5" network interface, which is the wired connection. If you use a wireless connection, instead of "ethx", the interface name will be something like "wlanx".




Figure 5: Wireshark Capture Options Window (Linux).



© edX Inc. All rights reserved except where noted. EdX, Open edX and the edX and Open EdX logos are registered trademarks or trademarks of edX Inc.

